





# INSTRUCTIONS

## C3 ST EL Instructions

- 1 Place hook on the middle of the handle of the lead shopping cart.



- 2 Place ratchet hook securely on the middle of the handle you use to push the line of carts.



- 3 Pull the rope through the ratchet with moderate force to create lift. **Do not over-tighten.**

- 4 **Important!** To remove the device:

- a Hold on to the C3 ST EL handle.
- b Lift up on the cart handle while pulling the release lever at the same time.



**Easing tension on the ratchet release lever as illustrated will extend it's useful life!**